


BE031XX




For XX:
AA=chrome
XG=silk black

Pos.	Signify	Spare parts-Nr.	Quantity	Pos.	Signify	Spare parts-Nr.	Quantity
1	Lever	B961980XX	1 Set				
2	Rubber cap	B961951NU	3 Pcs.				
3	Cap M38x1.5	B961373XX	1 Pcs.				
4	Screw M41x1.5-M38x1.5	B961374NU	1 Set				
5	Hot limit stop	A861181NU	1 Pcs.				
6	Cartridge Ø38mm	B961491NU*	1 Set				
7	Pull knob	B960486XX	1 Pcs.				
8	Aer.coin slot M24x1	A861436NU	1 Pcs.				
9	Diverter automatic	B960167XX	1 Set				
10	Non return valve	A960944NU	2 Pcs.				
11	Fixation set	A964520NU	1 Set				
12	Noice reducer	A963777AT	1 Set				

*Universal set (not all parts needed)

BE031XX



For XX:
AA=chrome
XG=silk black

Pos.	Signify	Spare parts-Nr.	Quantity	Pos.	Signify	Spare parts-Nr.	Quantity
1	Lever	B961980XX	1 Set				
2	Rubber cap	B961951NU	3 Pcs.				
3	Cap M38x1.5	B961373XX	1 Pcs.				
4	Screw M41x1.5-M38x1.5	B961374NU	1 Set				
5	Hot limit stop	A861181NU	1 Pcs.				
6	Cartridge Ø38mm	B961491NU*	1 Set				
7	Pull knob	B960486XX	1 Pcs.				
8	Aer.coin slot M24x1	A861436NU	1 Pcs.				
9	Diverter automatic	B960167XX	1 Set				
10	Non return valve	A960944NU	2 Pcs.				
11	Fixation set	A964520NU	1 Set				

*Universal set (not all parts needed)