




Pos.	Signify	Spare parts-Nr.	Quantity	Pos.	Signify	Spare parts-Nr.	Quantity
1	Lever	B961980XX	1 Set				
2	Rubber cap	B961951NU	3 Pcs.				
3	Rosette M41x1.5	B961386XX	1 Pcs.				
4	Screw M41x1.5/M46x1.5	B961387NU	1 Set				
5	Hot limit stop	A861181NU	1 Pcs.				
6	Cartridge Ø38mm	B961491NU*	1 Set				
7	O-Ring Ø18.2x1.7	A961640NU	2 Pcs.				
8	Nipple M22x1.5-G1/2	B961981NU	1 Set				
9	Non return valve	A963410NU	1 Pcs.				
10	S-connections	B960241AA	1 Set				

*Universal set (not all parts needed)