






Spare Parts / Ersatzteile / Pièces de recharge / Pezzi di Ricambio / Piezas de requesto /
Parte de reposição / Reserveonderdelen / Reservdelar / Reservedeler / Varaosat /
Vraosat / Varahlutir / Ανταλλακτικά / Yedek Parçalar / Náhradní díly / Náhradné diely /
Nadomestni deli / Резервни части / Запчасти / Części Zapasowe / Piese de schimb /
Rendelhető alkatrészek / Запасні частини / Reservni delovi / Резервни делови /
Резервни делови / Atsarginių dalių / Tellitavad varuosad / Reservju daļu

XX = AA, GN ..



Pos.	Part No.	
1	B 961 665 XX	
2	A 861 859 XX	
3	A 861 878 XX	
4	A 861 872 NU	
5	A 861 873 XX	
6	A 861 874 NU	
7	A 861 500 NU	
8	A 861 875 NU	
9	A 861 861 NU	
10	A 960 890 NU	
11	A 963 143 NU	
12	A 7851 XX	10mm
	A 7877 XX	20mm
13	A 960 704 NU	20mm
	A 962 476 NU	40mm




Joy
A8727 ..








Ideal Standard

1025 / A 869 312
Made in Germany



Ideal Standard International NV
Corporate Village – Gent Building
Da Vincilaan 2
1935 Zaventem
Belgium
www.idealstandard.com





			0	1	2	3	4	5
 P 0,3 MPa 3 bar			°C	°C	°C	°C	°C	°C
			50	49	44	40	35	33
			65	63	57	50	44	40
			85	83	74	64	56	50



 P	bar	 MAX. 10 0,5	 5 1		 Q (3 bar)
 T	°C	 MAX. 80	 65 55		 l/min 21