








Ordering spares / Ersatzteil - Regelung / Pièces de rechange / Parti di ricambio / Lista de recambios / Onderdelen bestellen (NL/B) / Κωδικοί Ανταλλακτικών / Bestilling af reservedele / Beställning av reservdelar / Bestilling av reservedeler / Резервни части / Запчасти / Części zapasowe / Piese de schimb / Rendelhető alkatrészek / Запасні частини / Резервни делови / Резервни делови / Atsarginių dalių / Tellitavad varuosad / Rezerves daļas / Náhradní díly / Náhradné diely / Yedek parça siparişi / Nadomestni deli

XX = AA, AD,


- | | |
|-----------------|------------------|
| 1 - A 961929 XX | 10 - B 960608 NU |
| 2 - A 963751 NU | 11 - A 961230 AA |
| 3 - B 961915 XX | B 961800 XX |
| 4 - B 961916 NU | 12 - A 962005 NU |
| 5 - B 961920 NU | 13 - B 960900 XX |
| 6 - B 960583 NU | |
| 7 - B 961662 XX | |
| 8 - B 961901 NU | |
| 9 - B 961253 NU | |




LDV


Ideal Standard

11.2023 / B565336




B D657 ..





B D658 ..














Ideal Standard International NV
Corporate Village – Gent Building
Da Vincilaan 2
1935 Zaventem
Belgium
<https://www.idealstandard.com>





4



P	T	°C	°C	°C	°C	°C
0,3 MPa 3 bar	50°C	15°C	27	33	41	48
	65°C	15°C	33	42	53	63
	85°C	15°C	41	53	68	83

	P	bar					Q (3 bar)
	T	°C					l/min
							3,8